

# Glove CAFE Installation, Operation and Maintenance



Made in the  
United States of America



Figure 1. Desco 19298 Glove CAFE

## Description

The Desco [19298](#) Glove CAFE (Constant Area and Force Electrode) meets ANSI/ESD SP15.1 requirements for measuring the intrinsic electrical resistance of gloves and finger cots. It also measures their electrical resistance together with personnel as a system.

The Desco Glove CAFE is compatible with the following Desco Surface Resistance Meters:

Item	Description
<a href="#">19290</a>	Digital Surface Resistance Meter Kit
<a href="#">19291</a>	Digital Surface Resistance Meter
<a href="#">19784</a>	Analog Surface Resistance Meter Kit
<a href="#">19786</a>	Analog Surface Resistance Meter
<a href="#">19640</a>	Surface Resistance Checker

## Packaging

- 1 Glove CAFE

## Operation

1. Fit a wristband snugly onto the wrist.
2. Snap the wrist cord to the wristband.
3. Plug the wrist cord into one input of the resistance meter.
4. Attach the Glove CAFE to the other input of the resistance meter.
5. Wear the glove on the same hand as the wristband and wait a minimum of 15 seconds before beginning the electrical measurement.

6. Balance the Glove CAFE on the fingerprint side of the thumb or first finger of choice on the hand wearing the glove.
7. Take a resistance measurement using the resistance meter.



Figure 2. Using the Glove CAFE Test Electrode with the Desco 19290 Digital Surface Resistance Meter

## Specifications

Dimensions	1.0" x 3.0" x 4.3" (25 mm x 76 mm x 109 mm)
Weight	1.0 lbs (454 g)
Country of Origin	United States of America

### Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the Desco Warranty - [Desco.com/Limited-Warranty.aspx](https://www.desco.com/Limited-Warranty.aspx)

DESCO WEST - 3651 Walnut Avenue, Chino, CA 91710 • (909) 627-8178  
DESCO EAST - One Colgate Way, Canton, MA 02021-1407 • (781) 821-8370 • Website: [Desco.com](https://www.desco.com)