

## Quick Start Guide

Secure the StatIQ Band around your upper arm in the orientation shown, ensuring that the sensor is unobscured and pointed away from your body.

**Use only with electrically dissipative clothing such as an ESD rated smock.**

### Power button

**Long press:** turn the device on and off

**Short press:** change the alarm mode

 **Yellow** → device muted

 **Green** → audible alarms enabled

### Alarms

**Constant alarm** → body voltage past threshold

**3 quick beeps** → ESD event detected

### IONA Tech App

Download the IONA Tech App from the App Store or Google Play Store to visualize the measured voltage data, change device parameters, and more.



### User Manual

Find the complete user manual at [www.iona.tech/manuals](http://www.iona.tech/manuals).

Please reach out to [info@gotopac.com](mailto:info@gotopac.com) or call **(888) 903-0333** for support.